

ROBINHOOD


INSTRUCTIONS AND SAFETY MANUAL

Read and follow all safety warnings and instructions in this manual. Failure to follow these instructions may cause serious or fatal injury!

Remain instructions and safety manual for future reference.

SAFETY RULES AND WARNINGS

1. This bow is NOT a toy. Adult supervision is recommended.
2. NEVER "Dry Fire" your bow! Do not pull back and release the string without an arrow attached to the string. Dry-firing a bow severely weakens the life expectancy of your bow and may cause immediate damage to the bow resulting in wound to yourself or others.
3. Do not point a drawn bow at anything other than an archery target. Make sure the area behind and around your target is clear. Never shoot arrows straight up in the air or in any direction where you might destroy property or endanger life.
4. Never use a damaged bow or damaged arrows! Inspect bow and arrows periodically for imperfections such as cracks, splits, or splinters. Inspect your bow, arrow shaft and nock each time before shooting. If any damage is detected, bow or arrow must be discarded immediately.
5. Replace your bowstring when it becomes worn or frayed.



6. Make sure the accessories are properly installed before shooting. Be sure all parts are secured and accessories are tight. Never use arrows that are too short or underweight.
7. Remember, look before you shoot! Be sure no one is standing in front of or to the sides of the archer while the bow is being drawn or shot! Be sure everyone is standing behind the archer.

Do not allow anyone to retrieve arrows until ALL arrows have been shot!

STRING THE BOW

1. Grasp the loose end of the string with your left hand and grasp the upper limb near the top with your right hand. Your right hand should be on the back of the bow.
2. Lay the curve of lower limb over left ankle. Step right foot over bow so that the face of the bow touches the back or your right thigh. Push slightly against the bow with your right hand.
3. Raise left heel off ground, lock right knee and push forward with the right hand so bowbends and push so bowbends naturally. Hook string onto the end of the bow and relax pressure slight.
4. Check to see that the string is seated properly before releasing remaining pressure.




Hook the String onto the tip


SHOOTING PREPARATION

Put the armguard on the arm with which you hold the bow. The armguard should cover the inside of your lower arm area to protect it from being slapped by the string when it is released.

HOLDING BOW AND ARROW



ARMGUARD POSITION




NOCKING THE ARROW

Before each shot, check all arrow components include nock, insert and tip. Make sure no cracks or dents on the shaft or loose nock. With a bow in the relaxed position, snap arrow nock onto the string in and keep your shaft align with the center of arrow rest and string.


READY TO SHOOT

Draw the bow string back to your jaw, anchor your first finger at the corner of your mouth. Keep your arm slightly bent, and keep your bow straight up and down, aim at your target and then release the bow string. Never release your string without an arrow nocked.

NOCKING THE ARROW



ARROW PLACEMENT



Place your Index finger on the upper side above the nock point and Middle and Ring fingers at the bottom under the arrow.

READY TO SHOOT

